Furniture care instructions

- do not push heavy objects with sharp edges and rough surfaces over the furniture
- avoid collisions with hard objects
- avoid high impact collisions of hard objects with surfaces and edges of the furniture
- when moving or handling the furniture, do not place any objects on the surfaces without using a soft and clean interleaving (eg. a blanket, a corrugated board)
- it is not suitable to use any type of polish on this furniture
- if any major mechanical damage occurs, expert assistance should be sought
- furniture surface is normally resistant to a short-term exposure to water, alcohol, high temperature, grease, chemicals and organic solvents
- the furniture must not be exposed to prolonged exposure to water do not put wet cloths, rags, etc. over the edges of cabinets and doors
- common dirt can be washed with lukewarm water with the addition of common liquid detergents and disinfectants, proportionately mixed in accordance with health care regulations
- use a properly wrung cloth while cleaning the furniture
- it is necessary to avoid using abrasive cleaners such as dish sands or scouring pads
- Chairs should be used only for sitting, do not put unsuitable objects on the chairs, do not climb, kneel or swing on them. Improper use of the chairs may cause damage to the product and increases the risk of a possible injury.
- the use of chemical solvents (trichlorethylene, acetone, petrol, etc.) for cleaning upholstered and wooden parts of the product is prohibited

If you follow these instructions, our product will serve you to your full satisfaction.